

## HIGH LEVEL/OVERFILL LIQUID LEVEL ALARM SENSORS LEVEL ALERT MODEL II™ OPERATIONAL TEST PROCEDURES

**IMPORTANT:** These instructions must be included in transfer procedures of all vessels so equipped. The Test Procedure outlined below must be performed on ALL High Level/Overfill Alarm Sensors prior to EVERY vessel loading per 46 CFR 39.20-9(b)3.

